




Bit Size Range	5-5/8 - 6-3/4 in	143 - 171 mm
Bit Box Connection	3-1/2 REGULAR	
Dynamic Bearing Load On/Off Bottom	71500 lbf	31800 daN
Static Bearing Load On/Off Bottom	229350 lbf	102000 daN
Max. Overpull (For Re-run)	328000 lbf	145900 daN
Absolute Overpull	546000 lbf	242900 daN
Adjustable Makeup Torque	12000 ft-lbs	16300 Nm
Stab/Thread Protector Makeup Torque	8000 ft-lbs	10800 Nm
A = Bit to Stabilizer (Centre)	15.7 in	0.4 m
B = Bit to Bend	Adjustable	55.8 in / 1.42 m
	Fixed	45.6 in / 1.16 m
C = Overall (With Dump Sub)	320.13 in	8.13 m
Weight	1257 lb	570 kg

Lobe Configuration	6-7 Lobe 7.0 Stage HR	
Displacement (No Load)	0.79 rev/gal	0.21 rev/l
Max. Differential (Full Load)	1650 psi	11376 kPa
Max. Torque	5350 ft-lbs	7254 Nm
Max. Power	244 HP	182 kW

Flow Rate		Speed
GPM	LPM	RPM
150	568	80 - 120
250	946	160 - 200
350	1325	240 - 280



ADJUSTABLE BUILD RATE

Hole Size	SLICK				STABILIZED			
	5-7/8 (149mm)	6 (152mm)	6-1/8 (156mm)	6-1/4 (159mm)	5-7/8 (149mm)	6 (152mm)	6-1/8 (156mm)	6-1/4 (159mm)
BEND ANGLE	Degrees per 100 Feet (30m)				Degrees per 100 Feet (30m)			
0.39	2.7	2.3	1.8	1.4	2.7	2.3	2.1	2.2
0.78	5.8	5.4	5.0	4.5	5.8	5.4	5.0	4.8
1.15	8.8	8.3	7.9	7.5	8.8	8.3	7.9	7.5
1.50	11.6	11.1	10.7	10.2	11.6	11.1	10.7	10.2
1.83	14.2	13.8	13.3	12.9	14.2	13.8	13.3	12.9
2.12	16.5	16.1	15.6	15.2	16.5	16.1	15.6	15.2
2.38	18.6	18.1	17.7	17.3	18.6	18.1	17.7	17.3
2.60	20.3	19.9	19.4	19.0	20.3	19.9	19.4	19.0
2.77	21.7	21.2	20.8	20.4	21.7	21.2	20.8	20.4
2.90	22.7	22.3	21.8	21.4	22.7	22.3	21.8	21.4
2.97	23.3	22.8	22.4	22.0	23.3	22.8	22.4	22.0
3.00	23.5	23.1	22.6	22.2	23.5	23.1	22.6	22.2

Note: Stabilizers are 1/8" undergauge

FBH BUILD RATE

Hole Size	SLICK				STABILIZED			
	5-7/8 (149mm)	6 (152mm)	6-1/8 (156mm)	6-1/4 (159mm)	5-7/8 (149mm)	6 (152mm)	6-1/8 (156mm)	6-1/4 (159mm)
BEND ANGLE	Degrees per 100 Feet (30m)				Degrees per 100 Feet (30m)			
1.25	9.4	8.9	8.4	7.8	9.4	8.9	8.4	8.4
1.50	11.4	10.9	10.4	9.8	11.4	10.9	10.4	10.2
1.75	13.4	12.9	12.3	11.8	13.4	12.9	12.3	12.0
2.00	15.4	14.9	14.3	13.8	15.4	14.9	14.3	13.8
2.25	17.4	16.9	16.3	15.8	17.4	16.9	16.3	15.8
2.50	19.4	18.9	18.3	17.8	19.4	18.9	18.3	17.8

This information is for reference only. Build rates are theoretical calculations using three-point geometry and new motor builds. Actual rate predictions will depend on formation characteristics, bit profiles, and WOB.

For custom motor configurations and build rates, please contact your DYNOMAX office.

FISHING DIMENSIONS

USC - IMPERIAL (Lengths, Diameters = in)
SI - METRIC (Lengths = m, Diameters = mm)



EXTERNALS		USC	SI
END CAP	A	8.5	0.22
BEARING HOUSING	B	--	--
PISTON HOUSING	C	11.5	0.29
STABILIZER SHOULDER	D	26.2	0.67
KICK/FIXED HOUSING	E	38.6	0.98
BIT TO BEND (ADJUSTABLE)	F1	55.8	1.42
ADAPTOR HOUSING (ADJUSTABLE)	G1	60.8	1.54
BIT TO BEND (FIXED)	F2	45.6	1.16
ADAPTOR HOUSING (FIXED)	G2	52.3	1.33
STATOR START	H	77.0	1.96
STATOR END	I	289.0	7.34
OVERALL LENGTH	J	320.1	8.13
BIT BOX Ø	K	4.63	117.6
END CAP/BEARING HOUSING Ø	L	5.15	130.8
THREAD PROTECTOR Ø	M	5.75	146.1
PISTON HOUSING Ø	N	5.15	130.8
KICK/FIXED HOUSING Ø	O	5.06	128.5
PAD (ADJUSTABLE) Ø	P1	5.50	139.7
PAD (FIXED) Ø	P2	5.38	136.7
ADJUSTABLE MANDREL PIN Ø	Q	2.81	71.4
ADAPTOR HOUSING Ø	R	5.06	128.5
ADAPTOR PIN Ø	S	3.35	85.1
STATOR TUBE OUTER Ø	T	5.00	127.0
STATOR TUBE INNER Ø	U	4.00	101.6
ROTOR CATCH SUB BLADE Ø	V	5.25	133.4
ROTOR CATCH SUB Ø	W	5.00	127.0



INTERNALS		USC	SI
BIT BOX	A	8.0	0.20
THRUST SHOULDER	B	16.2	0.41
WASHPIPE START	C	20.4	0.52
HEX END	D	25.7	0.65
BEARING ASSEMBLY ADAPTOR	E	37.5	0.95
BAA CAP	F	47.9	1.22
ROTOR ADAPTOR CAP	G	70.9	1.80
ROTOR START	H	76.9	1.95
ROTOR END	I	280.9	7.13
CATCH STEM	J	292.8	7.44
BIT BOX Ø	K	4.63	117.6
MANDREL Ø	L	3.63	92.2
THRUST Ø	M	3.13	79.5
WASHPIPE LARGE Ø	N	4.00	101.6
WASHPIPE SMALL Ø	O	3.00	76.2
BEARING ASSEMBLY ADAPTOR Ø	P	3.58	90.9
DRIVESHAFT Ø	Q	1.93	49.0
ROTOR ADAPTOR Ø	R	3.60	91.4
ROTOR MAJOR DIA. Ø	S	3.02	76.7
ROTOR CATCH STEM Ø	T	2.13	54.0

This information is for reference only. Assemblies are displayed in an "Adjustable Configuration"

Rotor Catch and Rotor Catch Float Sub Lengths may vary based on configuration, and use of Dump Subs or combination Rotor Catch and Float Housings.

If any additional information is required, please contact your local DYNOMAX office.